



2010 - 2017 Chevy Equinox / GMC Terrain

Part Number: D0070
D1070/D2070

TRIM LINE INSTRUCTIONS: Floor Mat trim patterns vary per vehicle make and model. If you need assistance with your install or have any questions, please call the Manufacturer **877-572-6227**, Monday - Friday between the hours of 8 a.m. - 5 p.m. (EST).

STEP 1

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the mat to regain it's custom shape after being rolled up for shipping.



Trim area is provided at the top of Cargo Liner for vehicles with a sliding 2nd row.

STEP 2

Use sharp scissors or a carpenter's knife to cut along crevice in mat to remove area for vehicles equipped with a sliding 2nd row.

Trimmed for vehicles with a sliding 2nd row.



TRIM AREA AFTER

