



2010 Or Newer Cadillac SRX

Part Number: D0087
D1087/D2087

TRIM LINE INSTRUCTIONS: Floor Mat trim patterns vary per vehicle make and model. If you need assistance with your install or have any questions, please call the Manufacturer **877-572-6227**, Monday - Friday between the hours of 9 a.m. - 5 p.m. (EST).

STEP 1

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the mat to regain it's custom shape after being rolled up for shipping.



If you do not use the D-Rings to secure your cargo, move the D-Rings to the position that is best for you and install the cargo liner. Prescored cut out area provided to expose D-Rings and U-Rail if needed.

STEP 2

Use sharp scissors or a carpenter's knife to cut along pre-scored area to accommodate D-Rings and U-Rail.



****CUT PRE-SCORED AREA ONLY AS SHOWN****
**** DO NOT CUT ANY OTHER AREA. ****

