



2011 - 2014 JEEP WRANGLER Unlimited

Part Number: D0139
D1139/D2139

TRIM LINE INSTRUCTIONS: Floor Mat trim patterns vary per vehicle make and model.
If you need assistance with your install or have any questions, please call the Manufacturer
877-572-6227, Monday - Friday between the hours of 8 a.m. - 5 p.m. (EST).

STEP 1

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the mat to regain it's custom shape after being rolled up for shipping.



Trim area for vehicles equipped with optional under seat subwoofer

TRIM AREA AFTER

STEP 2

Use sharp scissors or a carpenter's knife to cut along crevice in mat to remove area for vehicles equipped with optional under seat subwoofer.



Trimmed for vehicles equipped with optional under seat subwoofer.